

STARTING NUMBERS

Polaris AXYS RMK 800 (2016)

Fuel

RPM

4500	00	00	00	00
5500	00	00	-03	-07

PSI

4300	09	11	11	00
5500	14	15	17	18
6700	18	20	34	30
7500	26	33	40	38
8200	25	30	40	40

Extra Fuel

-02	-08	-15
-----	-----	-----

PSI	RPM
<4.6	3000-6330
ON	ON



www.BoonDockers.com

208-542-4411 (Local)
877-522-7805 (Toll Free)